











Note: please select the correct wiring harness (A-cables or B-cables) according to the shape and pin configuration of the factory car's plug.

supplied camera connection video tutorial

If your factory car has a Bose amplifier or a Infinity audio system, please use C-cables.

If you are using **A-cables** or **B-cables**, please follow the steps shown in picture **(1)**: Enter Settings → Factory (enter password 3368), then select Car Model and choose "NULL—OTHER—No protocol—Null."

If your car has steering wheel control buttons, to ensure they work properly, open the SWC app on the radio and follow the app's instructions to manually learn the steering wheel control keys (as shown in picture 2).





If you are using **C-cables**, to prevent issues with steering wheel controls, air conditioning, or volume not functioning properly, please follow the steps shown in image (3):

Press Settings → Factory (input password: 3368) → Car Model, and select "XP (Simple) — Hyundai/KIA — KX5 — 2016."



For more guidence/video tutorial, please copy this link or scan the QR code to enter into our official website: http://www.fancygod.com

## Instructions

