## **USE MANUAL**


Car Stereo radio for Toyota RAV4 2007-2012


**Central Control Disassembly and Operation** 

Post-installation rendering



## Rear Camera Signal Wire 6Pin USB 4Pin USB to connect Signal Wire 6Pin USB 4Pin USB to connect of clips and facing down). Radio antenna 3 Power Cable 9 9 3 4 5 6 6 8 9 9







For more guidence/video tutorial, please copy this link or scan the QR code to enter into our official website: http://www.fancygod.com

## Instructions







Wires color may be different due to various batches, but pin locations will be the same.

You can search Youtube video ID "VWCklCYwF5s" on Youtube to find our supplied camera connection video tutorial

If your factory radio matches the one in image 1, please use **C-Cables (XC-1380)**.





If your factory radio matches the one in image 2, please use **B-Cables (XC-392)**.



After connecting the cables, please be sure to follow these steps:

According to Image 3, please press "Settings"

- → "Factory Settings" (enter password 3368)
- → "Car Model," to choose "NULL—OTHER— No Protocol—Null."

If your car has steering wheel control buttons, according to Image 4, please open the SWC app on the radio and refer to the app's instructions to manually learn the steering wheel control keys.





## FCC warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not causeharmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.